

	Document Technical Specification	version: v0.03 status: date: 2012-02-29
project title: Reader-Host-Protocol - PUR-Extension		org

READER-HOST-PROTOCOL

PUR - EXTENSION

EN_DS - Reader-Host-Protocol - PUR-Extensions.docx	created by: Stefan Detter	page: 1 von 14
----------------------------------------------------	----------------------------------	-----------------------

	Document Technical Specification	version: v0.03 status: date: 2012-02-29
	project title: Reader-Host-Protocol – PUR-Extension	org

History of Change:

10.03.2010	sde	Created document	v0.01
21.06.2011	sde	Added Lock-Tag codes	v0.02
08.12.2011	sde	Added Gen2-EPC-Size, Added description for Read-From-Tag, Added notification values	v0.03

EN_DS - Reader-Host-Protocol - PUR-Extensions.docx	created by: Stefan Detter	page: 2 von 14
-------------------------------------------------------	----------------------------------	-----------------------

	Document Technical Specification	version: v0.03 status: date: 2012-02-29
	project title: Reader-Host-Protocol – PUR-Extension	org

1	Introduction.....	4
2	Parameter–Dictionary.....	5
2.1	Inventory Mode.....	6
2.2	Power Safe Setting	7
2.3	RSSI	7
2.4	Tag-Id-Behavior	8
2.5	Gen2-Link-Frequency	9
2.6	Gen2-Bit-Encoding.....	9
2.7	Gen2-Modulation Depth	10
2.8	Gen2-EPC-Size	10
3	Function Descriptions	11
3.1	Read-From-Tag (50-03)	11
3.2	Lock-Tag (50-05).....	11
4	Custom–Tag–Commands	12
4.1	NXP-Set-ReadProtect (01)	12
4.2	NXP-Clear-ReadProtect (02)	13
5	Notifications	14

	<p style="text-align: center;">Document</p> <p style="text-align: center;">Technical Specification</p>	<p>version: v0.03</p> <p>status:</p> <p>date: 2012-02-29</p>
<p>project title: Reader-Host-Protocol – PUR-Extension</p>		<p>org</p>

1 Introduction

This document describes the extensions to the standard RF-Embedded Reader-Host-Protocol for the PUR.

<p>EN_DS - Reader-Host-Protocol - PUR-Extensions.docx</p>	<p>created by: Stefan Detter</p>	<p>page: 4 von 14</p>
-----------------------------------------------------------	-----------------------------------------	------------------------------

	Document Technical Specification	version: v0.03 status: date: 2012-02-29
	project title: Reader-Host-Protocol – PUR-Extension	org

2 Parameter-Dictionary

Name	Address	Size	Description	Version
Inventory Mode	0x0000	1 Byte	The used inventory mode	
Power Safe Settings	0x0001	3 Bytes	The settings for the power safe	
RSSI	0x0002	1 Byte	Defines if the RSSI Value is sent to the host	
Tag-Id-Behavior-Mode	0x0003	1 Byte	Defines how the reader should behave if a tag is detected.	
Gen2-Link-Frequency	0x0020	1 Byte	The used link frequency	
Gen2-Bit-Encoding	0x0021	1 Byte	The used bit encoding	
Gen2-Modulation-Depth	0x0022	1 Byte	The used modulation depth	
Gen2-EPC-Size	0x0023	1 Byte	The expected EPC Size	v1.07

The Parameters that can be set and read with the commands Get-Param and Set-Param are shown in the following table:

EN_DS - Reader-Host-Protocol - PUR-Extensions.docx	created by: Stefan Detter	page: 5 von 14
----------------------------------------------------	----------------------------------	-----------------------

	Document Technical Specification	version: v0.03 status: date: 2012-02-29
	project title: Reader-Host-Protocol – PUR-Extension	org

2.2 Power Safe Setting

The power safe setting can be used to pulse the reader and so safe power. If turned on, the reader switches the field on and performs an inventory after which he switches off the field and sleeps for the specified time. After this time this process is restarted.

Data Structure:

1 byte	Switch (ON (0x01) / OFF (0x00))
2 byte	Sleep Time in milliseconds

Default:

Switch	0x00	OFF
Sleep Time	0x00FA	250 ms

2.3 RSSI

If the RSSI Setting is enabled, the RSSI Value of the detected tags is appended to every Inventory-Cyclic-Interrupt.

Data Structure:

1 byte	Switch (ON (0x01) / OFF (0x00))
--------	---------------------------------

Default:

Switch	0x00	OFF
--------	------	-----

EN_DS - Reader-Host-Protocol - PUR-Extensions.docx	created by: Stefan Detter	page: 7 von 14
----------------------------------------------------	----------------------------------	-----------------------

	Document Technical Specification	version: v0.03 status: date: 2012-02-29
	project title: Reader-Host-Protocol – PUR-Extension	org

2.4 Tag-Id-Behavior

With this option the reader be configured how, it should react if it detects a tag.

Data structure:

1 byte Tag-Id-Behavior-Enum

Possible settings:

Name	Value	Description
Send-Tag-Id-Immediately	0x00	Every time the reader detects a tag, it is immediately forwarded to the host.
Send-Tag-Id-Once	0x01	If the reader detects a tag, it forwards the tag-Id to the host and stores it into a temporary buffer. If the same tag is detected again in the same inventory round, it is no more forwarded to the host. The buffer is cleared at the start of each cyclic inventory.

Default:

Tag-Id-Behavior-Enum **0x00** Send-Tag-Id-Immediately

EN_DS - Reader-Host-Protocol - PUR-Extensions.docx	created by: Stefan Detter	page: 8 von 14
----------------------------------------------------	----------------------------------	-----------------------

2.5 Gen2-Link-Frequency

This option sets the used Link Frequency for the Gen2 protocol.

Data Structure:

1 byte Link-Frequency

Possible settings:

Value	Description
0x00	40 kHz
0x01	80 kHz
0x02	160 kHz
0x03	213 kHz
0x04	256 kHz
0x05	320 kHz

Default:

Link-Frequency 0x02 160 kHz

2.6 Gen2-Bit-Encoding

This option sets the used Bit-Encoding for the Gen2 protocol.

Data Structure:

1 byte Bit-Encoding

Possible settings:

Value	Description
0x00	FM0
0x01	Miller 2
0x02	Miller 4
0x03	Miller 8

Default:

Bit-Encoding 0x01 Miller 2

	Document	version: v0.03
	Technical Specification	status: date: 2012-02-29
project title: Reader-Host-Protocol – PUR-Extension		org

2.7 Gen2-Modulation Depth

This option sets the used Modulation Depth for the Gen2 protocol.

Data Structure:

1 byte Modulation-Depth in %

Default:

Modulation-Depth 0x64 100%

2.8 Gen2-EPC-Size

This option sets the expected EPC size of the tags that should be scanned. If the EPC size is set to a constant value, only tags with this EPC size are detected. If the EPC size is set to 0, all tags with different sizes are detected. For constant sizes only multiples of 2 are allowed.

Data Structure:

1 byte EPC Size

Possible settings:

Value	Description
0	Dynamic
2	2 Byte EPC
4	4 Byte EPC
...	...
12	12 Byte EPC
...	...
18	18 Byte EPC

Default:

EPC Size 12 Constant 12 Byte Size

EN_DS - Reader-Host-Protocol - PUR-Extensions.docx	created by: Stefan Detter	page: 10 von 14
----------------------------------------------------	---------------------------	-----------------

	Document Technical Specification	version: v0.03 status: date: 2012-02-29
	project title: Reader-Host-Protocol – PUR-Extension	org

3 Function Descriptions

3.1 Read-From-Tag (50-03)

If the byte size 0 is selected, the reader reads until the responses with a “Memory Overrun” error. But with using tags with bigger User Memory banks, the reader uses another stop condition. It reads at a maximum of 200 bytes, and then returns the 200 bytes. So if bigger amounts of data should be read, the Read-From-Tag function should be called as long as the read byte count is lower than 200 bytes.

3.2 Lock-Tag (50-05)

The lock tag command needs to types of codes to lock a tag. For a Gen2 tag these codes are:

```
typedef enum{
    UNLOCK                = 0x00,
    LOCK                  = 0x01,
    PERMALOCK             = 0x02,
    LOCK_AND_PERMALOCK    = 0x03,
} eRFE_LOCK_MODE;
```

```
typedef enum{
    KILL_PASSWORD         = 0x00,
    ACCESS_PASSWORD       = 0x01,
    EPC                    = 0x02,
    TID                    = 0x03,
    USER                  = 0x04,
} eRFE_LOCK_MEMORY_SPACE;
```

These codes are directly connected to the Gen2 standard. Further information about these codes and there meaning can be found there.

EN_DS - Reader-Host-Protocol - PUR-Extensions.docx	created by: Stefan Detter	page: 11 von 14
----------------------------------------------------	----------------------------------	------------------------

4 Custom-Tag-Commands

In this section the available custom tag commands are documented. These commands can be used by calling the command 05-10 of the Reader-Host-Protocol.

The available commands are:

Command	Value
NXP-Set-ReadProtect	0x01
NXP-Clear-ReadProtect	0x02

4.1 NXP-Set-ReadProtect (01)

This function transfers a NXP tag into the ReadProtect Mode. In this mode the tag only returns zeroes instead of its actual EPC.

Parameters: unsigned char **command**, unsigned char **tagIdCount**,
 unsigned char **tagId**[tagIdCount], unsigned long **accessPassword**,

Return Values: RFE_RET_VALUE **status**

Status Values: RFE_RET_SUCCESS, RFE_RET_ERR_ON_EXEC_OP, RFE_RET_ERR_COULD_NOT_WRITE,
 RFE_RET_ERR_WRONG_PARAM_COUNT, RFE_RET_ERR_WRONG_PARAM, Every TMI
 Return Code

Example: Set the tag 30-08-33-b2-dd-d9-01-40-35-05-00-00 to ReadProtect:

PC -> Reader

52 46 45 01 5010 02 12 03 01 0C 300833b2ddd9014035050000 12345678 04 cs

dataLength = 0x12
 command = 0x01 -> NXP-ReadProtect
 tagIdCount = 0x0C -> 12 Bytes
 tagId = 30-08-33-b2-33-33-01-40-35-05-00-00
 accessPassword = 0x12345678

Reader -> PC

52 46 45 01 5010 02 01 03 00 04 cs

dataLength = 0x01
 status = 0x00 -> RFE_RET_SUCCESS

5 Notifications

The available notifications are:

ID	Name	Value	Description
0	Antenna-Power-Changed	1 byte = (bool) on	The notification is sent every time the antenna power changes.
1	Frequency-Changed	3 byte = (long) frequency	The notification is sent every time the frequency changes.
2	Inventory-Round-Ended	0 byte	The notification is sent every time an inventory round ended.
3	LBT-RSSI-Value-Measured	2 byte = (short) value	The notification is sent every time the LBT implementations measured a new RSSI value.